



LISTA RICAMBI / ERSATZTEILLISTE / LIST OF SPARES

Numero Number	Descrizione Bezeichnung Description	Codice ricambio Ersatzteil-Nr. Spare part ref.
1	Pantografi Tipo 52/92 FS Stromabnehmer Typ 52/92 FS Pantographs Type 52/92 FS	HC8112
2	Circuito stampato principale Hauptplatine Main PCB	HL2660/02
3	Circuiti stampati luci + guide luce Platine mit LEDs + Lichtleiter Lights PCBs + lights diffusers	HL2660/03
4	Motore Motor-Satz Motor pack	HL2660/04
6	Timone di allontanamento per aggancio corto Kupplungsmechanik Coupler mechanism	HL2660/06
7	Carrello completo Drehgestell komplett Complete bogie	HL2660/07
8	Set assi con ruote Radsätze Wheels set	HL2660/08
9	Anelli di aderenza Haftreifen Traction tyres	HL2660/09

Configurazione luci - funzionamento digitale
Konfiguration der Lichtfunktionen im Digitalbetrieb
Lights configuration - Digital mode

OUTPUT	FUNZIONE / FUNKTION / FUNCTION
F0f	Luci bianche basse testata anteriore Untere Spitzenlichter (Frontseite) Low white lights front head
F0r	Luci bianche testata posteriore Untere Spitzenlichter (Rückseite) White lights rear head
AUX1	Luci rosse testata posteriore Rote Schlusslichter (Rückseite) Red lights rear head
AUX2	Luci rosse testata anteriore Rote Schlusslichter (Frontseite) Red lights front head
AUX3	Terzo faro anteriore Oberes drittes Spitzenlicht (Frontseite) Third front head light

Verificare sul manuale del decoder DCC installato la corrispondenza delle uscite con le funzioni F1, F2 ecc. (mappatura funzioni).
Überprüfen Sie anhand der Betriebsanleitung des Decoders die korrekte Zuordnung der Funktionsausgänge (Function mapping).
Check on the manual of the installed DCC decoder the mapping of the outputs with the functions F1, F2 etc. (functions mapping).